Backing-Up and Restoring PRO 700 Configurations & Data

Backing-up PRO 700 configurations and data will save:

- Run Screens
- Yield, Coverage and Machine Data
- Client, Farm, Field & Event
- Run Lines and Boundaries
- Other Display and Guidance Settings

Before backing-up, ensure that your current Case IH **USB** is in the PRO 700 screen and it has all configurations correct and current saved onto the USB.

When satisfied with configurations, power off the PRO 700 and **ONLY once powered off**, take out the USB.

With this USB, insert into a computer, and then copy all files from the USB onto the computer **OR** another **BLANK** USB.

Furthermore, when restoring from a USB, insert the USB Thumb Drive into the PRO 700 **before turning the screen on**. Once inserted, turn on the PRO 700, and the Screen will automatically restore all configurations.

This enables you to make copies of the data and copy onto another USB in the case where you are using more than one machine at any one time and want to make use of the same run lines, run screens and other data. Simply copy the data from the original USB onto another Case IH Genuine USB.

NOTE: For those that use AFS Software, please refer to our subsequent document advising on how to backup, delete and restore Run Screens and Machine Data when uploading maps from software onto your PRO 700 screens.